


AIR RING MAIN FITTINGS



MAKING A CONNECTION

CONNECTING PUSH-FIT

Cutting the pipe





Cut the pipe square. Ideally use a John Guest pipe cutter for rigid nylon pipe & aluminium pipe cutters for aluminium pipe. To avoid damage to the O-ring remove any burrs & sharp edges.

Making the push-fit connection



Push the pipe up to the pipe stop.

Check the connection is secure



Pull to check a secure connection is made. Test the system before use.



WITH O-RING THREAD SEAL

To disconnect, 1/4 turn the screw cap, push the collet & remove the pipe. Fittings are reusable.

Note: Whilst we recommend the use of John Guest rigid nylon pipe, John Guest fittings can also be used with copper or aluminium pipe.

2110

Ω

٦

REDUCER

STEM ADAPTOR

BSPP MALE

∇

STRAIGHT CONNECTOR

STRAIGHT CONNECTOR

JGPM0428E

BSPP MALE WITH O-RING THREAD SEAL

PART NUMBER	TUBE OD	THREAD	
JGPM011513E	15 mm	3/8" BSPP	
JGPM011514E	15 mm	1/2" BSPP	
JGPM011516E*	15 mm	3/4" BSPP	
JGPM011814E	18 mm	1/2" BSPP	
JGPM012216E	22 mm	3/4" BSPP	
JGPM012818E	28 mm	1" BSPP	

* No thread seal



PART NUMBER	TUBE OD	
JGPM0415E	15 mm	
JGPM0418E	18 mm	
JGPM0422E	22 mm	

28 mm



DEMOUNTING PUSH-FIT


Demounting push-fit fittings




To disconnect, ensure the system is depressurised. Push the collet towards the fitting & remove the pipe. Fittings are reusable.

CONNECTING & DEMOUNTING SCREW CAP

Connecting screw cap fittings



Demounting screw cap fittings





21	1	0

PART NUMBER	STEM OD	THREAD	
JGPM051513E	15 mm	3/8" BSPP	
JGPM051514E	15 mm	1/2" BSPP	
JGPM051814E	18 mm	1/2" BSPP	
JGPM052214E	22 mm	1/2" BSPP	
JGPM052216E	22 mm	3/4" BSPP	

Converts push-fit ends to male thread



PART NUMBER	STEM OD	TUBE OD	
JGPM061510E	15 mm	10 mm	
JGPM061512E	15 mm	12 mm	
JGPM061815E	18 mm	15 mm	
JGPM062215E	22 mm	15 mm	
JGPM062218E	22 mm	18 mm	
JGPM062815E	28 mm	15 mm	
JGPM062822E	28 mm	22 mm	

Thirteen