


BALL VALVES

To insert the tube into the fitting, insert it fully to the end, & to release, shut off the compressed air & push the sleeve gently to pull the tube out.

Be sure to select the product according to your needs, as hand valves vent the downstream line using a three-way method, so leakage may occur when fluids other than air are applied.



METRIC TUBE TO TUBE

STRAIGHT UNION VALVE EXHAUSTING SOLD IN PACKS OF 10



PART NUMBER	TUBE OD A	TUBE OD B
CDHVU0404	4 mm	4 mm
CDHVU0606	6 mm	6 mm
CDHVU0806	8 mm	6 mm
CDHVU0808	8 mm	8 mm
CDHVU1008	10 mm	8 mm
CDHVU1010	10 mm	10 mm
CDHVU1210	12 mm	10 mm
CDHVU1212	12 mm	12 mm

BSPT THREAD

HAND VALVE VALVE EXHAUSTING BSPT MALE SOLD IN PACKS OF 10



PART NUMBER	THREAD A	THREAD B
CDHVM0101	1/8" BSPT	1/8" BSPT
CDHVM0201	1/4" BSPT	1/8" BSPT
CDHVM0202	1/4" BSPT	1/4" BSPT
CDHVM0302	3/8" BSPT	1/4" BSPT
CDHVM0303	3/8" BSPT	3/8" BSPT
CDHVM0403	1/2" BSPT	3/8" BSPT
CDHVM0404	1/2" BSPT	1/2" BSPT

BSPP THREAD

HAND VALVE VALVE EXHAUSTING BSPP MALE SOLD IN PACKS OF 10



PART NUMBER	THREAD A	THREAD B
CDHVMG0101	1/8" BSPP	1/8" BSPP
CDHVMG0201	1/4" BSPP	1/8" BSPP
CDHVMG0202	1/4" BSPP	1/4" BSPP
CDHVMG0302	3/8" BSPP	1/4" BSPP
CDHVMG0303	3/8" BSPP	3/8" BSPP
CDHVMG0403	1/2" BSPP	3/8" BSPP
CDHVMG0404	1/2" BSPP	1/2" BSPP

SLIDE VALVES

HAND SLIDE VALVE METRIC MALE SOLD IN PACKS OF 10



PART NUMBER	THREAD
CDHSVM-M5	M5 x 0.8

BSPT MALE

PART NUMBER	THREAD
CDHSVM-01	1/8" BSPT
CDHSVM-02	1/4" BSPT
CDHSVM-03	3/8" BSPT
CDHSVM-04	1/2" BSPT
CDHSVM-06	3/4" BSPT